



"NCO" Damping Sheet

Installation:

1. Make the installation of the first panel of laminated plaster, whether on the ceiling or wall.
2. Before installing it, cut the Damping Sheet to the required size.
3. Apply synthetic glue on the surfaces of Damping Sheet and put glue in the inner side of the second laminated plaster panel.
4. Screw the second laminated plaster panel, with the Damping Sheet sandwiched between the two panels.
5. Do not forget an elastic joint between the floor and the side walls with the metal structure.