

## “NCO” DOORSET INSTALLATION METHOD

---

1. Check setting out & level of the door on site before installation work commence.
2. Check the door mark, dimensions & finishing before delivery the door and frame to the location.
3. Drilling holes and fixing anchor bolts/ dowel bar into the wall.
4. Spot welding the steel frame to the anchor bolt and dowel bar.
5. Checking the plumb, level, dimensions and right angle of the frame again.
6. Weld the frame to the anchor bolts/ dowel bar and ensure the frame erect rigid.
7. Install the hinges of the doors leaf and then fixed to the frame.
8. Checking the swing operation, plumb and setting out
9. Installing the ironmongery (locksets, handle...etc) to the door except door closer.
10. Checking the acoustic seal in good conditions and adjusting the seals in suitable tightness.
11. Install door closer before hand over of the door.